





- ◎ Use LED backlight 5.7-inch monitor
- ◎ Chinese / English subtitles, easy operation.
- ◎ Connecting with M-Code of CNC M/C (Any Brand)
- ◎ Adopting AC servo systems to perform in high-precision, high speed, large torque
- ◎ To match any brand of servo motors such as : Yaskawa, Mitsubishi, Delta, TECO
- ◎ To offer 36 sets compensation for backlash adjusting, every 10 degrees compensation once to achieve the best accuracy
- ◎ Optional HEIDENHAIN encoder to be closed-loop system
- ◎ Optional MPG hand wheel for workpiece adjusting

ITEM	SPECIFICATION	ITEM	SPECIFICATION
Min. Increment	0.001°	Backlash Adjustment	Adjusted by parameter screen 1 of 2
Programmable Angle	0.000~999.999 °	Standard Parameter Function	Input / Output interface, long press "."
Emergency Stop	Whole system stop	Programmable System	Accepted incremental / absolute value
Input Method	Keyboard input	Instruction Selecting	Program input instruction / Indexing and rotating instruction
Program Capacity	15 sets of program	Origin Adjustment	Origin offset compensation setting
Program Step Capacity	90 steps for each program	External start signal	Automatic operation by M-CODE
Homing	Machine homing / relative homing	Delay time	0.1 to 99.9 seconds of delay
Jump Function	Jump to the subroutine (JUMP)	Input Power	Three-phase AC-220V 50/60HZ
Cycle Loop	Step up to 999 times per cycle	Connection cable	Power cable / Motor cable / CNC connection cables



Program example (a circle drilling four holes, method of equal amount (90° degrees)) (program screen as shown below)

Step 1	Turn on the power	Step 5	Input numeric key for setting speed
Step 2	Press SCR key to enter the program edit screen	Step 6	Input 4 of numeric keys to enter (division into four units)
Step 3	Press 2 of numeric key to enter	Step 7	Press the MODE key to return main screen
Step 4	Input 360 (degrees) of numeric key to enter	Step 8	Press START key for operation

	Power switch		Back to the execution screen
	Emergency stop button		Page key: switching program page
	MPG(hand wheel) socket		Jog key: select the direction for table rotating
	Screen for info displayed		Cursor key: direction selecting
	Stop key		Switching key for system screen
	Numeric keys: enter the program and parameters		Selection key for program OP
	I. To be decimal point while program setting or parameter status II. Program code setting: press key 2 seconds while the program STEP1 of OP		Return to relative origin
	"+" and "-" key: be the function while program setting or parameter status"		Return to mechanical origin
	Insert a program while program setting		Enter key
	I. Long press 3 seconds for setting 0 degree of table while the execution status II. Delete a program while program setting		Start key